


Quick Installation Guide

AirGo[®] Misting System




READ AND SAVE THESE INSTRUCTIONS


1. PREPARE PUMP




2. INSTALL BRACKET




3. INSTALL PUMP (AIRGO)




INSTALL PUMP (AIRGO ALL TERRAIN)



4. CONNECT HOSE



5. CONNECT WATER SOURCE




OPERATION

Water supply requirements:
15–60 PSI, 140°F (60°C) max

1. Turn off fan.
2. Plug in misting pump (20 A circuit).
3. Turn on water source.
4. Press red button on pump filter to purge air.
5. Flip Power switch to ON.
6. Press Start switch.
7. Turn on fan.

To stop misting, flip Power switch to OFF and turn off water source.



CAUTION: Do not operate misting pump without filter.
CAUTION: Do not plug fan into outlet on misting pump.



Operating Instructions and Maintenance:
bigassfans.com/support

